



The New location of the 'Serial Numbers' on Impulse tools

Old Location



New Location

