


**REFERENCE ONLY
NO SPARE PARTS SUPPORT**

**Paslode Lite-Line N18-150
1-1/2" Narrow Crown Stapler
A10335 (NZ)**



PARTS LEGEND

N18-150

A10335

1	ES-18	NP Deflector, Exhaust	40	VS-07	NP Housing, Trigger Valve
2	OR-61	NP O-Ring	41	OR-14	NP O-Ring
3	M5X25	NP Screw SHC	42	SP-39	NP Spring
4	CA-15	NP Cap	43	TG-06	NP Lever, Trip
5	ES-19	NP Exhaust	44	TG-12	NP Trigger
6	OR-01	NP O-Ring	45	SM-10	NP Pin, Roll
7	CA-11	NP Guide, Valve	46	DL-04	NP Latch
8	OR-62	NP O-Ring	47	SM-03	NP Pin, Roll
9	WS-32	NP Gasket	48	M4	NP Nut
10	SP-01	NP Spring	49	M4X16	NP Screw (ALT M4*16)
11	OR-71	NP O-Ring	50	SM-10	NP Pin, Roll
12	PV-10	NP Valve, Main	51	FP-71	NP Front Plate Assembly
13	OR-04	NP O-Ring	52	P-28	NP Wear Plate
14	OR-55	NP O-Ring	53	M3X8	NP Screw (ALT M*8)
15	WS-33	NP Ring, Retaining	54	ST-19	NP Arm, Contact
16	OR-72	NP O-Ring	55	SM-36	NP Pin (SEQ Fire)
17	CY-18	NP Bulkhead	56	SM-11	NP Pin, Spring
18	OR-73	NP O-Ring	57	SM-37	NP Pin, Spring
19	CY-19	NP Cylinder	58	SM-38	NP Lever
20	OR-12	NP O-Ring	59	SP-36	NP Spring
21	M8	NP Nut	60	SM-39	NP Ball
22	WS-20	NP Washer	61	SW-09	NP Washer
23	OR-74	NP O-Ring	62	SW-10	NP Seal, Driver
24	PS-12	NP Piston	63	WS-01	NP Washer
25	DB-27	NP Driver Blade	64	HR-28	NP Hanger
26	PS-49	NP Driver & Piston Assembly	65	M5X16	NP Screw
27	BP-09	NP Bumper	66	BH5X12	NP Screw BH (ALT BH5*12)
28	BD-23	NP Body Housing	67	MZ-18	NP Magazine
29	M5	NP Nut	68	BH5X14	NP Screw BH (ALT BH5*14)
30	CA-12	NP Cap, Inlet	69	SP-37	NP Spring
31	VS-04	NP Cap, Trigger Valve	70	FC-29	NP Spacer, Fixed
32	OR-21	NP O-Ring	71	FD-11	NP Follower
33	OR-22	NP O-Ring	72	SP-06	NP Spring, Negator
34	OR-23	NP O-Ring	73	SP-07	NP Retainer, Spring
35	VS-05	NP Valve, Pilot	74	FC-30	NP Lever, Fixed Cover
36	OR-24	NP O-Ring	75	FC-31	NP Cover, Magazine
37	SP-02	NP Spring	76	SM-74	NP Pin, Step
38	OR-25	NP O-Ring	77	OR-103	NP O-Ring
39	VS-06	NP Stem, Trigger			

NP = Non-Procurable