



No.	Code	Name	No.	Code	Name
1	574396	CAP ASM.	41	613043	C-RING
2	613071	UM.HD.BOLT	42	613042	SPRING COLLAR
3	574394	FRONT BRACKET	43	613041	FEED PISTON STOP
4	574395	EXHAUST COVER	44	613039	SPRING
5	623149	HEX.SOC.HD.BOLT	45	613038	O-RING
6	613008	SPRING	46	574408	FEED PISTON
7	613009	WASHER	47	613036	O-RING
8	613010	O-RING	48	574409	FEED PAWL
9	613011	PISTON HEAD VALVE	49	574410	NOSE
10	613012	O-RING	50	613034	RETAIN RUBBER
11	613013	SEAL	51	574412	SPACER
12	613014	PLAIN WASHER	52	574413	SPRING
13	613015	PISTON STOPPER	53	574414	SPACER
14	613016	O-RING	54	574415	STEPPED PIN
15	574398	DRIVER ASSEMBLY	55	613071	UM.HD.BOLT
16	574399	CYLINDER	56	574416	DOOR LOCK
17	613019	O-RING	57	574417	SPRING
18	613020	CYLINDER RING	58	574418	STEPPED PIN
19	613021	COLLAR	59	574419	CHECK PAWL
20	613022	O-RING	60	613045	SPRING
21	574403	GASKET	61	574420	DOOR
22	574404	BODY ASM.	62	613047	RETAIN RUBBER
23	574495	LOGO LABEL	63	574421	NOSE ASM.
24	613025	O-RING	64	613124	SWITCH ASM.
25	613026	BUMPER	65	574423	E-RING
26	613027	O-RING	66	574425	RUBBER PAD
27	405312	HEX.SOC.HD.BOLT	67	505355	MODEL-LABEL (sequential)
28	613060	SPRING	67	505356	MODEL-LABEL (contact)
29	574407	TRIP PIN	68	574437	WARNING-LABEL
30	574422	ADJ. SHAFT ASM	69	613433	FLAT WASHER
31	574424	SAFETY LEVER	70	574428	UM.HD.BOLT
32	574426	LOCK NUT	71	574433	TRIGGER ASSEMBLY (sequential)
33	574427	NOSE COVER	71	574432	TRIGGER ASSEMBLY (contact)
34	574430	HEX.SOC.HD.BOLT	72	613053	SPRING
35	613617	AIR NIPPLE	73	574429	MAGAZINE
36	574400	HEX.SOC.HD.BOLT	74	613033	STEPPED PIN
37	574401	COVER	75	574436	'MAGAZINE COVER
38	574402	GASKET	76	574434	TRIP GUIDE
39	613031	ROLLED PIN	77	574435	ROLLED PIN
40	574411	ROLLED PIN			