

A Battery

Drives up to 4000 nails per charge




B Fuel

Drives up to 1200 nails



C Nails

16 ga. angled



See page 4
for

- D** - Drive nails
- E** - Adjusting depth of drive
- F** - Clearing nail jam

Cleaning Reference Guide



TrimMaster 16 gauge Angled Bradder Quick Reference Guide

D Drive nails

Always wear
safety glasses



1



2



3

E Adjusting depth of drive



1

F Clearing nail jam



1



2



3



4



Contact

Paslode Australia
Head Office

47 - 55 Williamson Road
Ingleburn
NSW 2565
Australia

www.paslode.com.au

A Division of ITW Australia Pty Ltd
ABN 63 004 235 063

Your nearest distributor: