

PARTS LEGEND

PASLODE COILMASTER IM50S (MK3)

B50001

1	919042	1 Grill	47	919104	1 Washer, Flat 6-32
* 2	900455	1 Filter	■ 48	919103	1 Screw SHC 6-32 x 0.375
3	901065	4 Screw SHC 10-24 x 1-1/4	* ● 49	503231	1 O-Ring, Feed Piston Shaft
4	919040	1 Cap	→ 50	919052-3	1 Piston, Feed
5	900902	3 Screw TF SEMS 8-32 x 5/8	51	919102	1 Pawl, Feed
6	902637	1 Limiter	● 52	503207	2 Pin, Feed Pawl
7	902644	1 Motor Assembly, Fan	* ● 53	503242	1 O-ring, Feed Piston
8	900287	1 Spark Plug Assembly	54	919096-1	1 Spring, Feed Piston
9	401356	1 Sleeve, Fan Motor	55	919069-1	1 Electromagnet
10	904517	1 Fuel Barb	56	904540	1 Bumper, Electromagnet
● 11	904546	1 Fuel Tube	57	919024	1 Housing, Electromagnet
12	902405	1 Fuel Block	58	919105	2 Screw SHC 8-32 x 3/8
13	904521	1 Pivot Arm, Fuel Tube	59	919141	1 Gate & Check Pawl Assembly
→ 14	919219	1 Cylinder Head	● 60	515434	2 Ring, Retaining PU
* ● 15	919067	4 Seal Ring, Cylinder Head and Sleeve	● 61	502989	1 Ring, Retaining PU
16	403167	1 Fan Blade Assembly	62	502999	1 Spring, Gate
17	919048	1 Air Dam	63	503202	1 Sleeve, Gate Hinge
→ 18	919228	1 Combustion Chamber Assembly	64	503203	1 Pin, Gate Hinge
■ 19	900969	4 Screw 8-32 x 5/8	→ 65	919161	1 Fuel Door Assembly
* ● 20	919045	1 O-Ring	67	919116	2 Screw SHC 8-32 x 3/8
■ 21	919065	4 Screw TX SEMS 8-32 x 1/4	68	919115	2 Bush
→ 22	919213	1 Bracket, Chamber Lockout	69	919130	1 Handle RH
23	919004	1 Ring, Retaining Circlip	70	900662	1 Wire Harness, ESU
* 24	919005	1 Driver & Piston Assembly	71	904717	1 Electronic Spark Unit (ESU)
* ● 25	900612	2 Seal Ring, Piston	72	919092	2 Nut, Nyloc 10-24
→ 26	919117	1 Sleeve Assembly	73	901095	1 Slide Switch Assembly
■ 27	900595	4 Screw TX SEMS 8-32 x 3/8	74	919068	1 Circuit Board Assembly
28	919010	1 Cover, Muffler	75	918903	2 Pad, Foam (Battery)
* ● 29	919049	1 Muffler	76	404702	3 Screw TF 6-19 x 3/8
* ● 30	919009	1 Reed Valve	→ 77	919121	1 Trigger Assembly
31	919011	1 Reed Plate	78	903728	1 Wire Lead Assembly, Spark
32	919016	1 Baffle, Exhaust	79	919063	1 Wire Lead Assembly, Fan Motor
* ● 33	919014	1 Seal, Exhaust	80	919075A	1 Hook Assembly Kit, Belt/Rafter
* ● 34	919017	1 O-Ring	81	919075	1 Hook, Belt/Rafter
* 35	919012	1 Bumper	82	919077	1 Block, Belt/Rafter Hook
36	919142	1 Housing Assembly	83	904532	1 Retainer, Trigger & Wire Lead
37	919046	1 Spring, Yoke	84	904705	1 Housing, Lockout Pin
38	919123	1 Yoke Assembly	→ 85	919217	1 Spring
39	018956	1 Wheel, Depth Adjustment	→ 86	919215	1 Pin, Lockout
● 40	919110	1 O-Ring, Retaining	→ 87	906129	1 Handle LH
41	919124	1 Probe Assembly	88	901066	4 Screw TF TX 8-16 x 3/4
* 42	576340	2 No Mar Tip	89	919093	2 Screw 10-24
■ 43	919108	4 Screw SHC SEMS 1/4-20 x 7/8	90	919031	1 Magazine Assembly
→ 44	919238	1 Nose Assembly	** 91	919083	1 Label, Data Plate and Warning
45	503244	1 Spring, Latch	92	919055	1 Pin, Magazine Hinge
46	503213	1 Latch	93	010031	AR Service Kit

* Normal Wear Item

** Ensure Warning Label is affixed and legible

● Included in Service Kit

■ Apply Loctite® 242 (Blue)

→ New Change

AR As Required

Remove battery, fuel & fasteners before commencing service.

Use eye and ear protection when operating/testing tools.

Use eye protection when cleaning tools.

Use degreaser in a well ventilated area.



WARNING: All parts must be periodically inspected and replaced if worn or damaged. Failure to comply can affect the tool's operation and present a safety hazard.